Art.-Nr. 10-10065
Thermocook Drip Tray



Description

The drip tray for the Thermocook is the essential accessory for keeping your work area clean and professional. Whether you are preparing waffles, paninis or donuts - the drip tray reliably collects dripping batter and excess fat.

- Hygienic and tidy: Keeps your Thermocook and the entire work area clean and presentable for customers at all times.
- Multifunctional application: Can be used for all Thermocook interchangeable plates.
- Easy cleaning: The drip tray is easy to clean after grilling, baking or frying. It is dishwasher-safe and particularly easy to maintain.
- High-quality material: PPS synthetic material is robust, heat-resistant and durable. Ideal for the demands of a professional kitchen.
- Compatibility for customer satisfaction: The drip tray for the Thermocook is also designed to fit the Neumärker Baking System or a Classic Waffle Maker, so that owners of older models can use the new drip tray on their already existing appliance.
- All-round protection: The grease tray consists of a front and a rear section to protect the Thermocook from dripping fat and batter all round.

Technical data

Width x depth x height:	(2x) 305 x 203 x 24 mm