# Art.-Nr. 10-10065
# Thermocook Drip Tray



## Description

The drip tray for the Thermocook is the essential accessory for keeping your work area clean and professional. Whether you are preparing waffles, paninis or donuts - the drip tray reliably collects dripping batter and excess fat.

- Hygienic and tidy: Keeps your Thermocook and the entire work area clean and presentable for customers at all times.
- Multifunctional application: Can be used for all Thermocook interchangeable plates.
- Easy cleaning: The drip tray is easy to clean after grilling, baking or frying. It is dishwasher-safe and particularly easy to maintain.
- High-quality material: PPS synthetic material is robust, heat-resistant and durable. Ideal for the demands of a professional kitchen.
- Compatibility for customer satisfaction: The drip tray for the Thermocook is also designed to fit the Neumärker Baking System or a Classic Waffle Maker, so that owners of older models can use the new drip tray on their already existing appliance.
- All-round protection: The grease tray consists of a front and a rear section to protect the Thermocook from dripping fat and batter all round.

## Technical data

| | |
|---|---|
| **Width x depth x height:** | (2x) 305 x 203 x 24 mm |